



Non-Contact Tool Setting NC4+



This presentation will give you step by step instructions on (re)aligning and (re)calibrating your laser tool setting system

Table of Content:



• Vertical Machines:

- Status LEDs page 4
- Adjustment..... page 5
 - Table Axis page 6
 - Spindle Axis page 7
- Calibration page 9

Maintenance:

- Troubleshooting..... page 10

Vertical Alignment LED status



Renishaw NC4+ Blue

Probe status LED	
Blocked beam / probe triggered	●
Partially blocked beam / probe untriggered	●
Unblocked beam / probe untriggered	●

- Fixed Renishaw laser systems, at rest, should always have Green LEDs
- If you have a NC4+ Blue, your status light should be BLUE
 - If they are any other color consult the 'Basic Troubleshooting page'

Renishaw NC4+

Red = no signal

Amber = some signal

Green = good signal



Fixed system adjustment



If laser is moved, update these coordinates
By driving the tool to the center of the laser
And recording the Machine XY position

```
(LASER ALIGNMENT)
(ALIGNMENT ERROR IN #102)
G28G91Z0
G00G40G80G90
G53X-12.8Y-26.46
#3006=150(MOVE TOOL INTO POSITION)
G65P9860T1B1.D2.K5.00012R.62543A-22.30Z.15
M30
```

- If you make any adjustments to your laser, you **must** run O8060 (alignment cycle) **then** O8061 (calibration cycle)
- When to align the laser:
 - You hit / bump the laser bracket.
 - If you think the system may have shifted / moved.
 - A change in the machines Grid Shift or Spindle
- Run O8060
 - Use caution when Manually driving the Laser Tool to the beam, as you may be able to crash into the laser body!
 - Looking at the LEDs change its status to 'Broken Beam' with the tool, then slightly back out, restoring the original LED status

Table Axis



- When the program stops on the M1
- Check Var #100 for alignment of the beam to the table axis. This value is an angle and should be under +/- .5 deg.
 - If #100 is an acceptable number go to page 18
- If you need to adjust lightly tap the connector side of the fixed system left or right
 - Hit cycle start and repeat until an acceptable number is found
- Move on to page 18

***If you need to adjust with a hammer
DO NOT HIT THE LASER HEADS!**

# Macro Variables		
Num	Value	Memo
100	0.7845986	ERROR ACROSS TABLE (ANGLE)
101	0.000181169	
102	-0.0146324	ERROR ACROSS SPINDLE (LEVEL)

This is not an acceptable value.

# Macro Variables		
Num	Value	Memo
100	0.023547990	ERROR ACROSS TABLE (ANGLE)
101	0.000162528	
102	-0.000250000	ERROR ACROSS SPINDLE (LEVEL)

This is an acceptable value.



Set screw / Cap screw type adjustment.
Direct table mount.




Loosen / Tighten type adjustment.
Pqi provided riser mount.

Spindle Axis



- Check Var #102 for the alignment along the spindle axis. This value should be less than ± 0.001 in.
- To adjust along the spindle axis you must adjust the level of the base. Depending on the setup on your machine the adjustment will either be by a set screw/cap screw type or a loosen/tighten type of setup.
 - If the NC4+ base is installed directly on the table then it will be the set screw/cap screw type setup.
 - If the NC4+ base is installed on a “riser” provided by PQI then the adjustment will be a loosen/tighten type setup. (next page)
- When adjusting with a M3 Alan-wrench, make sure to loosen first then tighten the opposite.



Set screw / Cap screw type adjustment.
Direct table mount.

- Make slight adjustments Hitting cycle start and repeat until #102 is an acceptable value
- Check that your Cap and Set Screws are snug. Run it one more time to ensure you still have good numbers
- If #100 and #102 are acceptable you **MUST** now run O8061

Macro Variables

Macro Variables Macro Variables Output File

#1- #100- #500- #98000- User

Num	Value	Memo
100	0.7845986	ERROR ACROSS TABLE (ANGLE)
101	0.000181169	
102	-0.0146324	ERROR ACROSS SPINDLE (LEVEL)

This is not an acceptable value.


Macro Variables

Macro Variables Macro Variables Output File

#1- #100- #500- #98000- User

Num	Value	Memo
100	0.023547990	ERROR ACROSS TABLE (ANGLE)
101	0.000162528	
102	-0.000250000	ERROR ACROSS SPINDLE (LEVEL)

This is an acceptable value.



Loosen / Tighten type adjustment.
PQI provided riser mount.


Calibration



- Double check that all values match your master tool exactly:
 - K (tool length)
 - R (reference tool diameter)
 - W (tool width)
 - Y (tool radius – .055 in)
- Run O8061
- After calibration Var #520-#531 are populated (This depends on the O9460 or O9760 settings program. The program number will depend on the age of Renishaw software.

- O9760 = TSM1(push in measurement)
or
- O9460 = TSM2(pull out measurement)) will be updated with the Laser Calibration values.
 - #120=520(BASE NUMBER)
- Do **NOT** overwrite the values in these macro variables with your own cycles.
- Now your laser is ready to use.

K= Length
R= Reference Diameter
W=Width (not on all Master Tools)



(LASER CALIBRATION)

```
G91G28Z0  
G90G80G49G40G0  
G65P9861B1.T1K5.00012R.62543Z.15  
G65P9861B1.T1K5.00012R.62543Z.15Y.272W.37436  
M30
```

***Some versions of software may have only one line in the calibration program.

(LASER CALIBRATION)

```
G91G28Z0  
G90G80G49G40G0  
G65P9861B1.T1K5.00012R.62543Z.15Y.272W.37436  
M30
```

Basic Troubleshooting



- If you have Red LED status
 - Check to see machine air is ON and air is coming out of laser heads
 - Check to see if Transmitting laser is hitting the Receiving head on center
- Amber LEDs
 - Re-align and Re-Calibrate laser
- Green / Amber rapidly flashing LEDs
 - Switch the set-up Switch 2 on the laser interface (page 6) for 5 seconds and then switch back.
- Is the laser-beam a 'shotgun pattern' not a 'pin-point'
 - Clean laser heads
- LEDs on laser won't turn on
 - Contact PQI
 - Office: 763-249-7149
 - Toll Free: 800-772-0620